



## **Magazine Loading Instructions for Model's MR-5.7 & MP-5.7**

**Caliber 5.7 x 28mm Magazine Capacity 9 Rounds**

To load the magazine push down the front of the follower with the rim of the first cartridge, then slide the round back under the magazine lips. Load the second cartridge in the same manor. After loading the first 2 cartridges, insert the straight portion of the magazine loading tool into the through hole on the side of the follower. This allows you to hook your thumb into the "U" shaped section of the loading tool and to then pull down with your thumb to relieve the spring pressure on the follower as you insert individual rounds.

Make sure the cartridge is all the way to the rear of the magazine before loading another cartridge. If the cartridge is not fully to the rear of the magazine, loading the next cartridge may cause damage to the point of the previous cartridge. The 5.7 x 28mm cartridge is a tight fit in the magazine.

**Do not pull the follower all the way down and start dumping in cartridges.**

Once you have loaded the magazine, give the back of the magazine a couple of sharp raps on a hard surface. This will normally cause the rounds to align and assume a proper loading posture.

To unload the magazine, push each cartridge forward until it is no longer held by the magazine lips.